


# 2008 AN112 PARTS DIAGRAM

Engine Cover(s)

E1431



## 2008 AN112 PARTS LIST

### Engine Cover(s)

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL,6X25 (Ref # 132)	132BD0625	6
BOLT-FLANGED-SMALL,6X35 (Ref # 132A)	132BD0635	9
BOLT-FLANGED-SMALL,6X45 (Ref # 132B)	132BD0645	3
SCREW-PAN-CROSS,6X35 (Ref # 220)	220AD0635	2
SCREW-PAN-CROSS,6X45 (Ref # 220A)	220AD0645	1
GASKET,GENERATOR (Ref # 11061)	11061-0125	1
GASKET,CLUTCH COVER (Ref # 11061A)	11061-0426	1
PLATE (Ref # 13270)	13270-1800	1
COVER-CHAIN (Ref # 14026)	14026-1284	1
COVER-GENERATOR (Ref # 14031)	14031-0015	1
COVER-CLUTCH (Ref # 14032)	14032-0021	1
COVER,HEAT INSULATOR (Ref # 14091)	14091-1444	2
CAP-OIL FILLER (Ref # 16115)	16115-1067	1
GAUGE,OIL LEVEL (Ref # 52005)	52005-0019	1
SCREW (Ref # 92009)	92009-1745	2
SEAL-OIL,S 12 28 7 HS (Ref # 92049)	92049-0051	1
SEAL-OIL,TB16267 (Ref # 92051)	92051-003	1
RING-O,31.5X2.6 (Ref # 92055)	92055-049	1
BOLT,SOCKET,5X10 (Ref # 92151)	92151-1212	6