


# 2008 AN112 PARTS DIAGRAM

## Ignition Switch



## 2008 AN112 PARTS LIST

### Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
CAP,IGNITION SWITCH (Ref # 11065)	11065-0149	1
SWITCH,REAR BRAKE (Ref # 27010)	27010-0044	1
LOCK-ASSY,SEAT (Ref # 27016)	27016-0010	1
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5352	1
SWITCH-ASSY (Ref # 27045)	27045-0007	1
SWITCH-ASSY (Ref # 27045A)	27045-5382	1
REFLECTOR-REFLEX (Ref # 28012)	28012-1081	1
SNAP,SEAT LOCK (Ref # 39124)	39124-0002	1
PLATE-THRUST (Ref # 49074)	49074-0001	1
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	5
WASHER,6.5X20X1.6 (Ref # 92022)	92022-1557	1
SPRING,REAR BRAKE SWITCH (Ref # 92145)	92145-0250	1
SPRING,REAR BRAKE SWITCH (Ref # 92145A)	92145-0545	1