


1988 Eliminator PARTS DIAGRAM

Rear Wheel/Chain

F2210-0207



1988 Eliminator PARTS LIST

Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
PANEL-ASSY-BRAKE,RR (Ref # 41035)	41035-1229	1
SHOE-BRAKE (Ref # 41048)	41048-1062	2
CAM-BRAKE (Ref # 41050)	41050-1065	1
LEVER-BRAKE CAM (Ref # 41053)	41053-1068	1
AXLE,RR (Ref # 41068)	41068-1192	1
WHEEL-ASSY,RR,F.BLACK (Ref # 41073A)	41073-1370-21	1
INDICATOR (Ref # 41085)	41085-1060	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1107	1
SLEEVE,L=25 (Ref # 42036)	42036-1055	1
SPROCKET-HUB,44T (Ref # 42041)	42041-1292	1
SPROCKET-HUB,44T (Ref # 42041A)	42041-1293	1
STUD,10X19 (Ref # 92004)	92004-1111	6
NUT,CASTLE,16MM (Ref # 92015)	42045-014	1
NUT,FLANGED,10MM (Ref # 92015A)	92015-1335	6
COLLAR,17X35X17.5 (Ref # 92027)	42032-068	1
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
SEAL-OIL,TWC35527 (Ref # 92049)	92052-006	1
CHAIN,DRIVE,EK520SV-OX114L (Ref # 92057)	92057-1240	1
DAMPER,RR HUB SHOCK (Ref # 92075)	92075-1436	1
SPRING,BRAKE SHOE (Ref # 92081)	42020-004	2
SEAL,BRAKE CAM (Ref # 92093)	41051-003	1
COLLAR,17.2X25X105 (Ref # 92143)	92143-1124	1
COLLAR,17.2X30X23.5 (Ref # 92143A)	92143-1125	1
BOLT-SMALL,8X28 (Ref # 114)	114G0828	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING-BALL,#6203ZZC3 (Ref # 601)	601B6203ZZ	1
BEARING-BALL,#6205G (Ref # 601A)	601B6205G	1
BEARING-BALL,#6303ZZC3 (Ref # 601B)	601B6303ZZ	1
O RING (Ref # 671)	671B2550	1