

1999 Vulcan 500 LTD PARTS LIST

Battery Case

| ITEM NAME | PART NUMBER | QUANTITY |
|--------------------------------------|-------------|----------|
| BOLT-FLANGED,6X14 (Ref # 130) | 130G0614 | 3 |
| BOLT-FLANGED (Ref # 130A) | 130J0610 | 2 |
| BOLT-FLANGED,6X16,BLACK (Ref # 130B) | 130J0616 | 3 |
| BOLT-FLANGED,8X14 (Ref # 130C) | 130J0814 | 2 |
| BOLT-FLANGED,10X55 (Ref # 130D) | 130J1055 | 2 |
| BOLT-FLANGED-SMALL (Ref # 132) | 132E0820 | 2 |
| BOLT-FLANGED-SMALL (Ref # 132A) | 132E0850 | 4 |
| CAP,PIVOT (Ref # 11012) | 11012-1821 | 2 |
| BRACKET,IGNITER (Ref # 11049) | 11049-1576 | 1 |
| BRACKET,AIR CLEANER (Ref # 11049A) | 11049-1577 | 1 |
| BRACKET,THERMOSTAT (Ref # 11049B) | 11049-1795 | 1 |
| COVER,BATTERY (Ref # 14090) | 14090-1688 | 1 |
| BRACKET-SWITCH (Ref # 32059) | 32059-1132 | 1 |
| BRACKET-MUFFLER,LH (Ref # 32069) | 32069-1453 | 1 |
| BRACKET-MUFFLER,RH (Ref # 32069A) | 32069-1454 | 1 |
| CASE-BATTERY (Ref # 32097) | 32097-1160 | 1 |
| CASE-BATTERY (Ref # 32097A) | 32097-1163 | 1 |
| CASE-TOOL (Ref # 32098) | 32098-1110 | 1 |
| CASE (Ref # 32099) | 32099-1170 | 1 |
| CASE (Ref # 32099A) | 32099-1177 | 1 |
| STAY,LH (Ref # 35011) | 35011-1757 | 1 |
| STAY,RH (Ref # 35011A) | 35011-1758 | 1 |
| TRIM,L=200 (Ref # 53044) | 53044-1299 | 1 |
| TRIM,L=100 (Ref # 53044A) | 53044-3728 | 4 |
| SCREW,6X10 (Ref # 92009) | 92009-1402 | 1 |
| SCREW,5X10 (Ref # 92009A) | 92009-1651 | 2 |
| SCREW,6X10 (Ref # 92009B) | 92009-1661 | 2 |
| NUT (Ref # 92015) | 92015-1700 | 1 |
| GROMMET (Ref # 92071) | 92071-3733 | 2 |

1999 Vulcan 500 LTD PARTS LIST

Battery Case

| ITEM NAME | PART NUMBER | QUANTITY |
|----------------------------|-------------|----------|
| BAND,L=142.1 (Ref # 92072) | 92072-006 | 1 |
| BOLT,6X16 (Ref # 92150) | 92150-1198 | 2 |
| DAMPER (Ref # 92160) | 92160-1439 | 1 |
| CLAMP (Ref # 92170) | 92170-1646 | 1 |