


# 2008 ER-6n (Australian) PARTS DIAGRAM

Ignition Switch

F2770



## 2008 ER-6n (Australian) PARTS LIST

### Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,5X12 (Ref # 120)	120CB0512	2
BOLT-FLANGED,6X12 (Ref # 130)	130BB0612	2
WASHER-SPRING (Ref # 461)	461L0600	2
BRACKET,SEAT LOCK (Ref # 11051)	11051-1370	1
ROTOR,LOCK,TANK CAP (Ref # 21007)	21007-5057	1
SWITCH-ASSY-IGNITION (Ref # 27005A)	27005-5139	1
KEY-LOCK,BLANK (Ref # 27008)	27008-0030	1
SWITCH,SIDE STAND (Ref # 27010)	27010-1455	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-1479	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-1115	1
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5309	1
SWITCH-ASSY (Ref # 27045A)	27045-5356	1
REFLECTOR-REFLEX (Ref # 28012)	28012-1077	1
BOLT,FLANGED,6X25 (Ref # 92002)	92002-1582	1
SCREW,6X14 (Ref # 92009)	92009-3845	2
WASHER,6.5X16X2 (Ref # 92022)	92022-1342	1
SPRING,REAR BRAKE SWITCH (Ref # 92145)	92145-0091	1
BOLT,TORX,6X16 (Ref # 92153)	92153-0967	2
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	1