


# 2004 Ninja<sup>®</sup> 250R PARTS DIAGRAM

Valve(s)

E1210



## 2004 Ninja® 250R PARTS LIST

Valve(s)

| ITEM NAME                                | PART NUMBER | QUANTITY |
|--|-------------|----------|
| VALVE-INTAKE (Ref # 12004)               | 12004-1074  | 4        |
| VALVE-EXHAUST (Ref # 12005)              | 12005-1091  | 4        |
| RETAINER-VALVE SPRING (Ref # 12009)      | 12009-1060  | 8        |
| COLLET (Ref # 12011)                     | 12011-1051  | 16       |
| ARM-ROCKER (Ref # 12016)                 | 12016-1067  | 8        |
| SEAT-SPRING,12.1X16.2X0.5 (Ref # 16007)  | 16007-1177  | 8        |
| SEAT-SPRING,17.5X23.8X0.5 (Ref # 16007A) | 16007-1178  | 8        |
| SPRING-ENGINE VALVE (Ref # 49078)        | 49078-1078  | 8        |
| SPRING-ENGINE VALVE (Ref # 49078A)       | 49078-1079  | 8        |
| SCREW,6MM (Ref # 92009)                  | 92009-1424  | 8        |
| NUT,6MM (Ref # 92015)                    | 92015-1586  | 8        |
| SEAL-OIL,VSB58.558 (Ref # 92049)         | 92049-1218  | 8        |