


# 1995 Ninja® 500 PARTS DIAGRAM

Valve(s)

E1210



## 1995 Ninja® 500 PARTS LIST

Valve(s)

| ITEM NAME                                | PART NUMBER | QUANTITY |
|--|-------------|----------|
| O RING,16MM (Ref # 670)                  | 670D2016    | 4        |
| VALVE-INTAKE (Ref # 12004)               | 12004-1119  | 4        |
| VALVE-EXHAUST (Ref # 12005)              | 12005-1052  | 4        |
| RETAINER-VALVE SPRING (Ref # 12009)      | 12009-1054  | 8        |
| COLLET (Ref # 12011)                     | 12011-1003  | 16       |
| ARM-ROCKER (Ref # 12016)                 | 12016-1051  | 4        |
| SHAFT-ROCKER (Ref # 12020)               | 12020-1057  | 4        |
| SEAT-SPRING,12.1X16.2X0.5 (Ref # 16007)  | 16007-1177  | 8        |
| SEAT-SPRING,17.5X23.8X0.5 (Ref # 16007A) | 16007-1178  | 8        |
| SPRING-ENGINE VALVE,INNER (Ref # 49078)  | 49078-1051  | 8        |
| SPRING-ENGINE VALVE,OUTER (Ref # 49078A) | 49078-1052  | 8        |
| SCREW,7MM (Ref # 92009)                  | 92009-1279  | 8        |
| NUT,7MM (Ref # 92015)                    | 92015-1325  | 8        |
| SEAL-OIL,RVC2-5.5X8.5X8.3 (Ref # 92049)  | 92049-1062  | 8        |
| SPRING,ROCKER ARM (Ref # 92081)          | 92081-1636  | 4        |