


1988 X2 PARTS DIAGRAM

Fuel Pump

E1520-0011



1988 X2 PARTS LIST

Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
VALVE-CHECK,FUEL PUMP (Ref # 16087)	16087-3701	2
COVER-PUMP,FUEL (Ref # 16142)	16142-3701	1
DIAPHRAGM,PULSE (Ref # 43028)	43028-3702	1
DIAPHRAGM,FUEL (Ref # 43028A)	43028-3703	1
PACKING,PULSE CASE (Ref # 43049)	43049-3703	1
PACKING,FUEL COVER (Ref # 43049A)	43049-3704	1
PUMP-FUEL (Ref # 49040)	49040-3703	1
CASE-PUMP,PULSE (Ref # 59336)	59336-3704	1
CASE-PUMP,BODY (Ref # 59336A)	59336-3705	1
SCREW,3X6 (Ref # 92009)	92009-3707	2
SCREW,5X25 (Ref # 92009A)	92009-3708	3
NUT,3MM (Ref # 92015)	92015-3731	2
CLAMP,11MM (Ref # 92037)	92037-3723	2
TUBE,PULSE,5.8X10.8X330 (Ref # 92059)	92059-3812	1