


1990 TS PARTS DIAGRAM

Fuel Pump

E1520



1990 TS PARTS LIST

Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
BRACKET (Ref # 11046)	11046-3795	1
VALVE-CHECK,FUEL PUMP (Ref # 16087)	16087-3701	2
COVER-PUMP,FUEL (Ref # 16142)	16142-3702	1
DIAPHRAGM,PULSE (Ref # 43028)	43028-3702	1
DIAPHRAGM,FUEL (Ref # 43028A)	43028-3703	1
PACKING,PULSE CASE (Ref # 43049)	43049-3705	1
PACKING,FUEL COVER (Ref # 43049A)	43049-3706	2
PUMP-FUEL (Ref # 49040)	49040-3706	1
CASE-PUMP,PULSE (Ref # 59336)	59336-3704	1
CASE-PUMP,BODY (Ref # 59336A)	59336-3707	1
BOLT,6X25 (Ref # 92002)	92002-3714	4
BOLT,6X40 (Ref # 92002A)	92002-3716	2
SCREW,3X6 (Ref # 92009)	92009-3707	2
SCREW,5X28 (Ref # 92009A)	92009-3767	3
NUT,3MM (Ref # 92015)	92015-3731	2
CLAMP,11MM (Ref # 92037)	92037-3723	4
COLLAR,6X8.5X13 (Ref # 92143)	92143-3715	4
DAMPER (Ref # 92160)	92160-3733	4
TUBE (Ref # 92190)	92059-3857	1
TUBE (Ref # 92190A)	92059-3876	1