


1984 LTD Shaft PARTS DIAGRAM

AIR CLEANER

E1130-0147



1984 LTD Shaft PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR,FR (Ref # 11010)	11010-1148	1
FILTER-ASSY-AIR,RR (Ref # 11010A)	11010-1149	1
FILTER-ASSY-AIR,FR (Canada) (Ref # 11010B)	11010-1152	1
FILTER-ASSY-AIR,FR (Ref # 11010C)	11010-1225	1
CAP,AIR FILTER (Ref # 11012)	11012-1183	1
ELEMENT,AIR CLNR (Ref # 11013)	11013-1013	1
BRACKET-A,AIR FILTER, (Ref # 11036)	11036-1514	2
COVER,AIR FILTER,LH,C (Ref # 14025B)	14025-1570	1
COVER,AIR FILTER,RH,C (Ref # 14025C)	14025-1571	1
DUCT,AIR FILTER,FR (Ref # 14073)	14073-1083	4
VALVE ASSY,AIR SWITCH (Ref # 16126)	16126-1017	1
FITTING,TUBE (Ref # 92005)	92005-1017	1
SCREW,TAPPING,5X12 (Ref # 92009A)	92009-1319	6
CLAMP-PIPE (Ref # 92037)	92037-072	6
CLAMP (Ref # 92037A)	92037-1076	1
CLAMP,BREATHER TUBE (Ref # 92037B)	92037-213	4
RING-O,91MM (Ref # 92055)	92055-1137	1
TUBE,VACUUM,LONG (Ref # 92059)	92059-1162	2
TUBE,4X9X220L (Ref # 92059A)	92059-1040	1
TUBE,AIR FILTER BLEED (Ref # 92059B)	92059-1170	1
TUBE,AIR (Ref # 92059C)	92059-1208	2
TUBE,L=355 (Ref # 92059D)	92059-1448	1
GROMMET,AIR CLEANER (Ref # 92071)	92071-1013	1
GROMMET,AIR FILTER (Ref # 92071A)	92071-1114	1
SPRING,AIR FILTER DUC (Ref # 92081)	92144-1771	4
BOLT 6X14 (Ref # 187A)	187B0614	4
SCREW-PAN-WP-CROS (Ref # 224)	224B0612	2
TUBE-RUBBER,4X330 (Ref # 702)	702A04330	1