


1983 LTD Shaft PARTS DIAGRAM

AIR CLEANER



E1130-0083



1983 LTD Shaft PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
GASKET,HOLDER (Ref # 11009)	11039-003	1
FILTER-ASSY-AIR (Ref # 11010)	11010-1128	1
FILTER-ASSY-AIR (Canada) (Ref # 11010A)	11010-1129	1
CAP,AIR CLEANER (Ref # 11012)	11012-069	1
ELEMENT,AIR CLNR (Ref # 11013)	11013-1060	1
BRACKET-A,AIR FILTER, (Ref # 11036)	11036-1357	1
BRACKET-A,AIR FILTER, (Ref # 11036A)	11036-1401	1
HOLDER,INLET PIPE (Ref # 13091)	11033-006	1
HOLDER,ELEMENT (Ref # 13091A)	13091-1147	1
COVER,AIR FILTER,LH,C (Ref # 14025)	14025-1582	1
COVER,AIR FILTER,RH,C (Ref # 14025A)	14025-1583	1
INLET DUCT (Ref # 14073)	14073-1032	4
VALVE ASSY,AIR SWITCH (Ref # 16126)	16126-1005	1
SILENCER (Ref # 39162)	39162-1003	1
FITTING,TUBE (Ref # 92005)	92005-1017	1
SCREW,TAPPING,5X12 (Ref # 92009)	92009-1144	4
CLAMP-PIPE (Ref # 92037)	92037-072	6
CLAMP (Ref # 92037A)	92037-1076	2
CLAMP,BREATHER TUBE (Ref # 92037B)	92037-213	4
TUBE,VACUUM,LONG (Ref # 92059)	92059-1162	2
TUBE,4X9X290 (Ref # 92059A)	92059-1043	1
TUBE (Ref # 92059B)	92059-1065	1
TUBE (Ref # 92059C)	92059-1066	1
TUBE,11X26X135 (Ref # 92059D)	92059-1137	1
TUBE,14X20X290 (Ref # 92059E)	92059-1138	1
GROMMET (Ref # 92071)	92071-1027	1
SPRING,COIL,BLACK (Ref # 92081)	92081-1457	4
BOLT HEX HEAD 6X12 (Ref # 110)	110B0612	2
WASHER PLAIN 6MM (Ref # 411)	411B0600	2

1983 LTD Shaft PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
WASHER SPRING 6MM (Ref # 461)	461F0600	2
TUBE-RUBBER,6X200 (Ref # 702)	702A06200	1