


1985 Tecate PARTS DIAGRAM

FRONT FORK ('85 A2)



1985 Tecate PARTS LIST

FRONT FORK ('85 A2)

ITEM NAME	PART NUMBER	QUANTITY
GASKET FORK DRAIN PLG (Ref # 11009)	44045-002	2
GASKET,FORK CYLINDER (Ref # 11009A)	44045-057	2
CAP,VALVE AIR (Ref # 11012)	11012-1391	2
VALVE,AIR (Ref # 16126)	16126-1117	2
FORK-FRONT (Ref # 44001)	44001-1559	1
PIPE-LEFT FORK OUTER (Ref # 44005)	44005-1222	1
PIPE-RIGHT FORK OUTER (Ref # 44006)	44006-1222	1
PIPE-FORK INNER (Ref # 44013)	44013-4003	2
CYLINDER-FORK (Ref # 44022)	44022-4003	2
SPRING-FRONT FORK (Ref # 44026)	44026-1284	2
SPRING-FRONT FORK,UPP (Ref # 44026A)	44026-4005	2
GUIDE-FORK SPRING (Ref # 44028)	44028-029	4
HOLDER-FORK UNDER (Ref # 44037)	44037-4005	1
HOLDER-FORK UPPER (Ref # 44039)	44039-1116	1
WASHER (Ref # 44043)	44043-052	1
BOOTS,FORK (Ref # 49006)	49006-1009	2
LABEL,FRONT FORK (Ref # 56040)	56040-1120	1
BOLT-FORK CYLINDER (Ref # 92001)	44041-040	2
BOLT,FORK TOP (Ref # 92001A)	44041-065	1
BUSHING,FORK (Ref # 92028)	92028-1365	2
RING-SNAP,FORK OIL (Ref # 92033)	92033-1100	2
SEAL-OIL,FORK OUTER P (Ref # 92049)	92049-1216	2
RING-O,FORK SPRING SE (Ref # 92055)	92055-1135	2
BAND,BOOTS (Ref # 92072)	92072-1008	2
DUST SHEILD,FORK (Ref # 92093)	44010-032	2
SEAL,FORK OUTER PIPE (Ref # 92093A)	92093-1181	2
BOLT-UPSET-WP-SMALL (Ref # 184)	184G0840	4
BOLT-UPSET-WP-SMALL (Ref # 184A)	184G0855	4
SCREW PAN HEAD 4X8 (Ref # 220)	220B0408	2

1985 Tecate PARTS LIST

FRONT FORK ('85 A2)

ITEM NAME	PART NUMBER	QUANTITY
SCREW-PAN-CROS (Ref # 220A)	220B0414	2
NUT,8MM (Ref # 317)	317G0800	4
WASHER PLAIN 8MM (Ref # 410)	410B0800	4