


1985 KLT160 PARTS DIAGRAM

RECOIL STARTER

E5090-0002



1985 KLT160 PARTS LIST

RECOIL STARTER

ITEM NAME	PART NUMBER	QUANTITY
GASKET,RECOIL STARTER (Ref # 11009)	11009-1394	1
CAP,RECOIL GRIP (Ref # 11012)	11012-1420	1
GUIDE,RECOIL (Ref # 13070)	13070-1123	1
PLATE-FRICTION,RECOIL (Ref # 13088)	13088-1059	1
SHAFT,RECOIL (Ref # 13107)	13107-1129	1
PAWL,RECOIL (Ref # 13165)	13165-1110	1
COVER,RECOIL (Ref # 14024)	14025-1966	1
GRIP,RECOIL (Ref # 46075)	46075-1057	1
PULLEY-STARTING (Ref # 49080)	49080-1051	1
STARTER-RECOIL (Ref # 49088)	49088-1051	1
REEL (Ref # 59101)	59101-1105	1
ROPE,RECOIL (Ref # 59106)	59106-1102	1
BOLT,10X40 (Ref # 92002)	92002-1296	1
NUT,6MM (Ref # 92015)	92015-1464	1
PIN,RECOIL (Ref # 92043)	92043-1259	1
RING-O,16.8MM (Ref # 92055)	92055-1235	1
SPRING,RECOIL (Ref # 92081)	92081-1772	1
SPRING,PAWL (Ref # 92081A)	92081-1773	1
SCREW-PAN-CROS, 6X14 (Ref # 220)	220C0614	4