


# 1986 Tecate PARTS DIAGRAM

FRONT FORK

F237U-0203



# 1986 Tecate PARTS LIST

## FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
GASKET,FORK DRAIN PLU (Ref # 11009)	11009-1553	2
GASKET FORK DRAIN PLG (Ref # 11009A)	44045-002	2
CAP,VALVE AIR (Ref # 11012)	11012-1391	2
VALVE (Ref # 16126)	16126-1147	2
FORK-FRONT (Ref # 44001)	44001-1602	1
PIPE-LEFT FORK OUTER (Ref # 44005)	44005-1237	1
PIPE-RIGHT FORK OUTER (Ref # 44006)	44006-1237	1
PIPE-FORK INNER (Ref # 44013)	44013-1235	2
PISTON-FORK,INNER PIP (Ref # 44018)	44018-1051	2
CYLINDER-FORK (Ref # 44022)	44022-1184	2
SPRING-FRONT FORK,UPP (Ref # 44026)	44026-1310	2
SPRING-FRONT FORK,LWR (Ref # 44026A)	44026-1311	2
GUIDE-FORK SPRING (Ref # 44028)	44028-1056	4
HOLDER-FORK UNDER (Ref # 44037)	44037-1190	1
HOLDER-FORK UPPER (Ref # 44039)	44039-1128	1
WASHER (Ref # 44043)	44043-052	1
BUSHING,FRONT FORK (Ref # 44065)	44065-1064	2
HOLDER-HANDLE,LWR (Ref # 46012)	46012-1124	2
BOOT,FORK (Ref # 49006)	49006-1182	2
LABEL,FRONT FORK (Ref # 56040)	56040-1120	1
BOLT,FORK TOP (Ref # 92001)	44041-065	1
BOLT,FORK DRAIN (Ref # 92002)	92002-1650	2
NUT,LOCK,10MM (Ref # 92015)	92019-021	2
WASHER,FORK OUTER TUB (Ref # 92022)	92022-1298	2
WASHER-HANDLEBAR FIT (Ref # 92022A)	92022-196	4
SPACER (Ref # 92026)	92026-1262	2
COLLAR,10.5X15.1X6 (Ref # 92027)	92027-1850	2
CIRCLIP (Ref # 92033)	92033-1036	2
SEAL-OIL,FORK (Ref # 92049)	92049-1245	2

# 1986 Tecate PARTS LIST

## FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
RING-O (Ref # 92055)	92055-1321	2
BAND,BOOT (Ref # 92072)	92072-1077	2
BAND (Ref # 92072A)	92072-1166	1
BAND (Ref # 92072B)	92072-1204	1
BAND (Ref # 92072C)	92072-1206	2
DAMPER,HANDLE HOLDER (Ref # 92075)	92075-1725	2
BUSHING-RUBBER (Ref # 92092)	92092-1053	2
SEAL,FORK (Ref # 92093)	92093-1206	2
BOLT-UPSET-WP-SMALL (Ref # 184)	184G0840	8
SCREW PAN HEAD 4X8 (Ref # 220)	220B0408	2
SCREW PAN HEAD 4X16 (Ref # 220A)	220B0416	2
PIN COTTER 2.0X20 (Ref # 550)	550D2020	2