


# 1986 Ninja® 250R PARTS DIAGRAM

REAR WHEEL/HUB/CHAIN



# 1986 Ninja® 250R PARTS LIST

## REAR WHEEL/HUB/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
AXLE,RR (Ref # 41068)	41068-1221	1
WHEEL-ASSY,RR,WHITE N (Ref # 41073)	41073-1333-T6	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1107	1
SLEEVE,L=25 (Ref # 42036)	42036-1055	1
SPROCKET-HUB,42T (Ref # 42041)	42041-1235	1
STUD,10X21 (Ref # 92004)	92004-1111	6
NUT CASTLE 16M/M (Ref # 92015)	42045-014	1
NUT,FLANGED,10MM (Ref # 92015A)	92015-1335	6
COLLAR,RR HUB (Ref # 92027)	92027-1784	1
COLLAR,RR HUB (Ref # 92027A)	92027-1785	1
CIRCLIP,47M/M (Ref # 92033)	92033-1042	1
OIL SEAL,AG1556EO (Ref # 92049)	92049-1056	1
OIL SEAL WTC35527 (Ref # 92049A)	92052-006	1
DR CHAIN EK520 104L (Ref # 92057)	92057-1159	1
DAMPER (Ref # 92075)	92075-1436	1
COLLAR,17.2X25X97 (Ref # 92143)	92027-1993	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BALL BEARING,#6203ZC3 (Ref # 601)	601B6203Z	1
BEARING BALL #6205 (Ref # 601A)	601B6205	1
BEARING BALL #6303Z (Ref # 601B)	601B6303Z	1
O RING (Ref # 671)	671B2550	1