


1991 SC PARTS DIAGRAM

Electrical Equipment

F3181



1991 SC PARTS LIST

Electrical Equipment

| ITEM NAME | PART NUMBER | QUANTITY |
|--|-------------|----------|
| HOLDER (Ref # 13091) | 13091-3762 | 3 |
| WIRE-LEAD,BATTERY-RELAY (Ref # 26011) | 26011-3783 | 1 |
| WIRE-LEAD,STARTER-RELAY (Ref # 26011A) | 26011-3784 | 1 |
| WIRE-LEAD,BATTERY-STARTER (Ref # 26011B) | 26011-3793 | 1 |
| BATTERY,YB16CL-B,12V 19AH (Ref # 26012) | 26012-3716 | 1 |
| BAND,L=123 (Ref # 92072) | 92072-030 | 1 |
| BAND (Ref # 92072A) | 92072-3778 | 2 |