


1987 Ninja® 600 PARTS DIAGRAM

FRONT WHEEL/HUB

F2230-0131



R	4
N	4
	4
	4
	4
	4
	5
	5
	5
	5
	5
	5
	5
	5
	5

1987 Ninja® 600 PARTS LIST

FRONT WHEEL/HUB

ITEM NAME	PART NUMBER	QUANTITY
GEAR-METER SCREW,24T (Ref # 41060)	41060-1025	1
GEAR-METER SCREW,9T (Ref # 41060A)	41060-1035	1
RECEIVER,SPEEDOMETER (Ref # 41064)	41064-1006	1
AXLE,FR (Ref # 41068)	41068-1164	1
WHEEL-ASSY,FR,WHITE N (Ref # 41073)	41073-1299-T6	1
CASE-ASSY-METER GEAR (Ref # 41078)	41078-1057	1
WASHER THRST SPD PINI (Ref # 92022)	41063-001	1
WASHER THRST SPD PINI (Ref # 92022A)	41063-001	1
COLLAR,FR AXLE L=30MM (Ref # 92027)	92027-1225	1
COLLAR,L=70 (Ref # 92027A)	92027-1725	1
COLLAR,&NUT,FR AXLE,L (Ref # 92027B)	92027-1726	1
CIRCLIP,42MM (Ref # 92033)	92033-1041	2
PIN,SPRING (Ref # 92043)	41082-001	1
OIL SEAL,BJN30427-C3 (Ref # 92049)	92049-1057	1
OIL SEAL,AG1144AO (Ref # 92049A)	92049-1058	1
BUSHING,METER GEAR (Ref # 92087)	92087-1002	1
BEARING-BALL (Ref # 601)	601B6302U	2