


# 1973 Midi-Bike PARTS DIAGRAM

FRONT HUB/BRAKE (MC1-A/B)



# 1973 Midi-Bike PARTS LIST

## FRONT HUB/BRAKE (MC1-A/B)

ITEM NAME	PART NUMBER	QUANTITY
NUT 10MM (Ref # 1)	42045-005	1
WASHER PLAIN 10MM (Ref # 2)	411B1000	2
PANEL-ASY,FR BRK BUFF (Ref # 3)	41035-058-80	1
BOLT-UPSET (Ref # 4)	112G0630	1
LEVER FRONT BRAKE CAM (Ref # 5)	41053-005	1
NUT,6MM (Ref # 6)	41072-007	1
INDICATOR,FR BK SHOE (Ref # 7)	41085-013	1
"0" RING,11MM (Ref # 8)	92055-004	1
WASHER THRST SPD PINI (Ref # 9)	41063-001	2
PINION-SPEEDOMETER (Ref # 10)	41060-014	1
BUSH,SPEEDMETER CABLE (Ref # 11)	41062-005	1
PIN,SPRING (Ref # 12)	41082-001	1
CAM SHAFT-FRONT BRAKE (Ref # 13)	41050-018	1
GEAR,SPEEDOMETER (Ref # 14)	41060-1026	1
RECEIVER,SPEED GEAR (Ref # 15)	41064-010	1
OIL SEAL BRAKE PANEL (Ref # 16)	92050-002	1
SHOE-BRAKE (Ref # 17)	41048-1085	2
SHOE-BRAKE (Ref # 17)	41048-1085	2
SPRING,BRAKE SHOE (Ref # 18)	92081-1766	2
DRUM-ASSY,FR BRK (Ref # 19)	41034-1040	1
BEARING BALL #6300Z (Ref # 20)	601B6300Z	1
SPACER FRONT HUB (Ref # 21)	41039-002	1
BEARING BALL #6200 (Ref # 22)	601B6200	1
OIL SEAL,TC17317 (Ref # 23)	92050-063	1
COLLAR,FRONT AXLE (Ref # 24)	41069-026	1
DUST SHIELD FRNT DRUM (Ref # 25)	41042-002	1
AXLE-FRONT (Ref # 26)	41068-039	1