


1974 G4TR-D PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL ('74-'75)



1974 G4TR-D PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL ('74-'75)

| ITEM NAME | PART NUMBER | QUANTITY |
|----------------------------------|-------------|----------|
| BAR,L.H FOOTREST (Ref # 1) | 34003-047 | |
| BAR,R.H FOOTREST (Ref # 2) | 34003-048 | |
| STEP-ASSY,FR,LH (Ref # 3) | 34027-1114 | |
| STEP-ASSY,FR,LH (Ref # 3-1) | 34027-1114 | |
| STEP-ASSY,FR,RH (Ref # 4) | 34027-1115 | |
| STEP-ASSY,FR,RH (Ref # 4-1) | 34027-1115 | |
| PIN-FOOTREST BAR FIT (Ref # 5) | 92043-080 | |
| WASHER PL 22.5X36X2.3 (Ref # 6) | 92022-204 | |
| PIN COTTER 2.5X16 (Ref # 7) | 550D2516 | |
| BOLT-UPSET,10X20 (Ref # 8) | 112B1020 | |
| WASHER PLAIN 10MM (Ref # 9) | 410B1000 | |
| NUT 10MM (Ref # 10) | 315B1000 | |
| BAR SET-REAR FOOTREST (Ref # 11) | 34030-001 | |
| RUBBER REAR FOOTREST (Ref # 12) | 92076-008 | |
| WASHER PLAIN 10MM (Ref # 13) | 410B1000 | |
| WASHER SPRING 10MM (Ref # 14) | 461F1000 | |
| NUT,10MM (Ref # 15) | 314B1000 | |
| PEDAL,BRAKE (Ref # 16) | 43001-055 | |
| PIN COTTER 3.0X30 (Ref # 17) | 550D3030 | |
| WASHER BRAKE PEDAL (Ref # 18) | 92022-085 | |
| PIN-BRAKE ROD FITTING (Ref # 19) | 92043-064 | |
| ROD ASSY,BRAKE (Ref # 20) | 43010-016 | |
| WASHER PLAIN 6MM (Ref # 21) | 410B0600 | |
| PIN COTTER 2.0X15 (Ref # 22) | 550D2015 | |
| SPRING,BRAKE ROD (Ref # 23) | 43012-001 | |
| PIN BRAKE (Ref # 24) | 92043-039 | |
| NUT-BRAKE ROD ADJUST (Ref # 25) | 92015-042 | |
| STAND-SIDE (Ref # 26) | 34024-028 | |
| SPRING MAIN STAND (Ref # 27) | 34023-005 | |