


1972 G4TR-B PARTS DIAGRAM

SEAT/CARRIER ('74-'75)



1972 G4TR-B PARTS LIST

SEAT/CARRIER ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
SEAT ASSY,DUAL (Ref # 1)	53002-052	
SEAT ASSY,DUAL (Ref # 1)	53002-1017	
SEAT ASSY,DUAL (Ref # 1)	53002-1017	
HOOK,SEAT (Ref # 2)	53008-020	
HINGE B (Ref # 3)	53009-018	
PIN (Ref # 4)	53011-002	
COTTER PIN (Ref # 5)	92041-003	
DAMPER RUBBER,SEAT (Ref # 6)	92075-216	
BOLT-UPSET 6X14 (Ref # 7)	112B0614	
WASHER PLAIN 6MM (Ref # 8)	411B0600	
WASHER SPRING 6MM (Ref # 9)	461F0600	
STAND,SEAT (Ref # 10)	53054-003	
SPRING,SEAT HOOK (Ref # 11)	53055-001	
PIN COTTER 2.0X15 (Ref # 12)	550D2015	
LOCK ASSY,SEAT (Ref # 13)	53045-014	
KEY SET,#401 (Ref # 14)	27008-063-01	
KEY SET,#410 (Ref # 14)	27008-063-10	
BOLT-UPSET,6X12 (Ref # 15)	112G0612	
WASHER PLAIN 6MM (Ref # 16)	411B0600	
WASHER SPRING 6MM (Ref # 17)	461F0600	
CARRIER,LUGGAGE (Ref # 18)	53029-050	
BOLT HEX HEAD 10X35 (Ref # 19)	113N1035	
WASHER PLAIN 10MM (Ref # 20)	411B1000	
WASHER SPRING 10MM (Ref # 21)	461F1000	
NUT 10MM (Ref # 22)	315B1000	
BOLT-SMALL,8X32 (Ref # 23)	114N0832	
WASHER SPRING 8MM (Ref # 24)	461F0800	
NUT,8MM (Ref # 25)	311B0800	