



# 1972 F6-A PARTS DIAGRAM

AIR CLEANER/MUFFLER



# 1972 F6-A PARTS LIST

## AIR CLEANER/MUFFLER

ITEM NAME	PART NUMBER	QUANTITY
MUFFLER ASSY (Ref # 1 ~ 5)	18001-032	
MUFFLER ASSY (Ref # 1 ~ 5)	18001-032	
BAFFLE TUBE (Ref # 2 ~ 5)	18033-073	
TAIL PIECE (Ref # 3)	18048-015	
WASHER LOCK 6MM (Ref # 4)	463H0600	
BOLT-UPSET,6X12 (Ref # 5)	112G0612	
BOLT-UPSET,6X12 (Ref # 5)	112G0612	
COVER-MUFFLER (Ref # 6)	18064-005	
WASHER LOCK 6MM (Ref # 7)	463H0600	
SCREW PAN HEAD 6X12 (Ref # 8)	220E0612	
INSULATOR (Ref # 9)	18065-007	
INSULATOR-HEAT (Ref # 10)	18065-009	
DAMPER RUBBER-MUFFLER (Ref # 11)	18063-005	
COLLAR (Ref # 12)	92027-102	
WASHER,8X26X2.3 (Ref # 13)	92022-1564	
WASHER SPRING 8MM (Ref # 14)	461F0800	
BOLT HEX HEAD 8X25 (Ref # 15)	116B0825	
AIR CLEANER ASSY (Ref # 16 ~ 2)	11010-040	
BODY-AIR CLEANER (Ref # 16)	11011-012	
ELEMENT,AIR CLNR (Ref # 17)	11013-020	
CAP-AIR CLEANER (Ref # 18)	11012-015	
"O" RING,100MM (Ref # 19)	671B25100	
GASKET-AIR CLEANER (Ref # 20)	11017-007	
DAMPER RUBBER (Ref # 21)	92075-051	
COLLAR (Ref # 22)	92027-103	
WASHER 6.5X20X1.6T (Ref # 23)	92022-125	
WASHER SPRING 6MM (Ref # 24)	461F0600	
BOLT-UPSET,6X20 (Ref # 25)	112G0620	
COLLAR 6.8X10X10.5 (Ref # 26)	92027-120	

# 1972 F6-A PARTS LIST

## AIR CLEANER/MUFFLER

ITEM NAME	PART NUMBER	QUANTITY
GROMMET (Ref # 27)	92071-046	
CLAMP,AIR CLEANER (Ref # 28)	92037-129	
CONNECTOR (Ref # 29)	11026-003	
CLAMP,AIR CLEANER (Ref # 30)	92037-128	
SCREW PAN HEAD 6X35 (Ref # 31)	220B0635	
BOLT-AIR CLEANER FIT (Ref # 32)	92003-066	
BOLT-AIR CLNR. FITTNG (Ref # 33)	92003-067	
COLLAR (Ref # 34)	92027-127	
COLLAR (Ref # 35)	92027-128	
AIR CLEANER ASSY (Ref # 36 ~ 4)	11010-061	
BODY-AIR CLEANER (Ref # 36)	11011-024	
ELEMENT,AIR,CLNR (Ref # 37)	11013-036	
HOLDER-CLENER ELEM (Ref # 38)	11014-007	
CAP-AIR CLEANER,BL (Ref # 39)	11012-028	
SCREW PAN HEAD 6X35 (Ref # 42)	220B0635	
SCREW PAN HEAD 6X30 (Ref # 45)	220B0630	
BOLT-UPSET (Ref # 46)	112G0625	
WASHER SPRING 6MM (Ref # 47)	461F0600	