


1972 F7-A PARTS DIAGRAM

FENDERS (F7-A)



1972 F7-A PARTS LIST

FENDERS (F7-A)

| ITEM NAME | PART NUMBER | QUANTITY |
|---------------------------------|--------------|----------|
| FENDER-FR,RED (Ref # 1) | 35004-055-73 | |
| BRACKET-FRONT FENDER (Ref # 2) | 35012-013 | |
| PLATE FRONT FENDER (Ref # 3) | 35013-003 | |
| FLAP-FR FENDER,RUBBER (Ref # 4) | 35019-004 | |
| PLATE-FR FENDER FLAP (Ref # 5) | 35020-007 | |
| SCREW PAN HEAD 6X12 (Ref # 6) | 220E0612 | |
| WASHER 6.5X20X1.6T (Ref # 7) | 92022-125 | |
| WASHER SPRING 6MM (Ref # 8) | 461F0600 | |
| NUT 6MM (Ref # 9) | 312B0600 | |
| BOLT-UPSET (Ref # 10) | 112G0625 | |
| NUT 6MM (Ref # 11) | 311B0600 | |
| SCREW PAN HEAD 6X14 (Ref # 12) | 220E0614 | |
| WASHER PLAIN 6MM (Ref # 13) | 410B0600 | |
| BOLT-UPSET,6X12 (Ref # 14) | 112G0612 | |
| FENDER-RR (Ref # 15) | 35022-053 | |
| FENDER-RR,RED (Ref # 16) | 35022-054-73 | |
| BRACE-REAR FENDER (Ref # 17) | 35034-012 | |
| BRACKET-REAR FENDER (Ref # 18) | 35025-019 | |
| GROMMET HARNESS 10MM (Ref # 19) | 92071-010 | |
| GROMMET HARNESS 10MM (Ref # 20) | 92071-019 | |
| BOLT-UPSET 6X14 (Ref # 21) | 112B0614 | |
| COLLAR (Ref # 22) | 92027-122 | |
| BOLT-UPSET (Ref # 23) | 112G0618 | |
| WASHER 6.5X20X1.6T (Ref # 24) | 92022-125 | |
| PLATE-GROUND WIRE (Ref # 25) | 26015-001 | |
| COLLAR (Ref # 26) | 92027-103 | |
| DAMPER RUBBER (Ref # 27) | 92075-051 | |
| SCREW PAN HEAD 6X14 (Ref # 28) | 220B0614 | |
| WASHER PLAIN 6MM (Ref # 29) | 411B0600 | |

1972 F7-A PARTS LIST

FENDERS (F7-A)

| ITEM NAME | PART NUMBER | QUANTITY |
|----------------------------------|-------------|----------|
| WASHER PLAIN (Ref # 30) | 92022-024 | |
| BOLT-SMALL-UPSET (Ref # 31) | 115B0832 | |
| SPACER FUEL TANK MONT (Ref # 32) | 92027-012 | |
| DAMPER RUBB TANK FRNT (Ref # 33) | 92075-013 | |
| WASHER,8X26X2.3 (Ref # 34) | 92022-1564 | |
| WASHER SPRING 8MM (Ref # 35) | 461F0800 | |
| NUT,8MM (Ref # 36) | 311B0800 | |