


1974 F11-A PARTS DIAGRAM

KICKSTARTER MECHANISM ('73-'75 F11/F11-A)



1974 F11-A PARTS LIST

KICKSTARTER MECHANISM ('73-'75 F11/F11-A)

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP (Ref # 1)	92033-026	
SPRING (Ref # 2)	92081-097	
RATCHET (Ref # 3)	13078-005	
RATCHET (Ref # 3)	13078-007	
WASHER-PLAIN 25MM (Ref # 4)	92022-159	
GEAR-KICKSTARTER (Ref # 5)	13068-025	
SHAFT-KICKSTARTER (Ref # 6)	13066-027	
SHAFT,KICKSTARTER (Ref # 6)	13066-041	
GUIDE-KICK SPRING (Ref # 7)	13070-004	
SPRING-KICKSTARTER (Ref # 8)	92082-003	
F11PEDAL ASSY,KICK (Ref # 9~14)	13064-017	
PEDAL ASSY,KICK (Ref # 9~14)	13064-017	
BOSS-KICK PEDAL (Ref # 10)	13061-014	
SPRING KICK PEDAL (Ref # 11)	92081-020	
BALL STEEL 1/4' (Ref # 12)	600A0800	
WASHER BRAKE PEDAL (Ref # 13)	92022-085	
WASHER,PLAIN (Ref # 13)	92022-277	
CIRCLIP 10MM (Ref # 14)	482J0100	
RUBBER KICK PEDAL (Ref # 15)	13063-004	
BOLT-HEX HEAD,10X25 (Ref # 16)	114B1025	
STOPPER-KICKSTARTER (Ref # 17)	13072-001	
GUIDE-KICKSTARTER (Ref # 18)	13206-007	
WASHER-LOCK (Ref # 19)	92024-036	
BOLT-UPSET,6X16 (Ref # 20)	112G0616	