


1974 F11-A PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL



1974 F11-A PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
STEP-ASSY,FR,LH (Ref # 1)	34027-1114	
STEP-ASSY,FR,LH (Ref # 1)	34027-1114	
WASHER PL 22.5X36X2. (Ref # 2)	92022-204	
PIN-FOOTREST BAR FIT (Ref # 3)	92043-080	
PIN,COTTER,2.5X15 (Ref # 4)	550D2515	
BRKT LH FOOTREST BAR (Ref # 5)	34007-010	
STEP-ASSY,FR,RH (Ref # 6)	34027-1115	
STEP-ASSY,FR,RH (Ref # 6)	34027-1115	
BRACKET, RH. FOOTREST BAR (Ref # 7)	34007-011	
BOLT-HEX HEAD,14X32 (Ref # 8)	113B1432	
WASHER SPRING 14MM (Ref # 9)	461F1400	
STAND-SIDE (Ref # 10)	34024-034	
SPRING-SIDE STAND (Ref # 11)	34025-004	
BOLT,HEX HEAD 10X35 (Ref # 12)	92001-1252	
NUT,10MM (Ref # 13)	314B1000	
PEDAL-BRAKE (Ref # 14)	43077-001	
SPRING-BRAKE PEDAL (Ref # 15)	43005-019	
LEVER-BRAKE PEDAL (Ref # 16)	42029-019	
BOLT-UPSET (Ref # 17)	112G0625	
BOLT-UPSET (Ref # 17)	112G0625	
WASHER SPRING 6MM (Ref # 18)	461F0600	
ROD-BRAKE (Ref # 19)	43011-011	
PIN-BRAKE ROD FITTIN (Ref # 20)	92043-064	
WASHER PLAIN 6MM (Ref # 21)	410B0600	
PIN COTTER 2.0X15 (Ref # 22)	550D2015	
SPRING,BRAKE ROD (Ref # 23)	43012-001	
PIN-BRAKE ROD (Ref # 24)	92043-065	
NUT-BRAKE ROD ADJUST (Ref # 25)	92015-042	