


1978 KZ400-A2 PARTS DIAGRAM

FRONT HUB



1978 KZ400-A2 PARTS LIST

FRONT HUB

ITEM NAME	PART NUMBER	QUANTITY
AXLE,FRONT (Ref # 1)	41068-045	
COLLAR,FRONT AXLE (Ref # 2)	41069-028	
DRUM-ASSY,FR BRK,BUFF (Ref # 3)	41034-038-80	
OIL SEAL,WTC22427 (Ref # 4)	92052-011	
CIRCLIP,42MM (Ref # 5)	92033-1041	
CIRCLIP,42MM (Ref # 5)	92033-1041	
BEARING BALL #6302 (Ref # 6)	601B6302	
COLLAR,FR HUB BEARING (Ref # 7)	41039-026	
OIL SEAL,WTC40528 (Ref # 8)	92052-012	
GEAR BOX ASSY (Ref # 9)	41078-006	
PIN,SPRING (Ref # 10)	41082-001	
WASHER THRST SPD PINI (Ref # 11)	41063-001	
PINION,SPEEDOMETER (Ref # 12)	41060-016	
BUSH,SPEEDMETER CABLE (Ref # 13)	41062-005	
DRIVE,SPEED,GEAR (Ref # 14)	41064-012	
GEAR,SPEEDOMETER (Ref # 15)	41059-025	
NUT,14MM (Ref # 16)	42045-020	
PIN COTTER 3.0X25 (Ref # 17)	550D3025	
WASHER PLAIN 14MM (Ref # 18)	410B1400	