


1975 KX400 PARTS DIAGRAM

KICKSTARTER MECHANISM



1975 KX400 PARTS LIST

KICKSTARTER MECHANISM

ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 1)	92022-252	1
CIRCLIP (Ref # 2)	92033-026	2
SPRING (Ref # 3)	92081-097	1
WASHER-PLAIN 25MM (Ref # 4)	92022-159	1
RATCHET (Ref # 5)	13078-007	1
GEAR,KICKSTARTER (Ref # 6)	13068-029	1
SHAFT,KICKSTARTER (Ref # 7)	13066-031	1
GUIDE,KICKSTARTER (Ref # 8)	13070-007	1
SPRING-KICKSTARTER (Ref # 9)	92082-003	1
PEDAL ASSY,KICK (Ref # 10)	13058-060	1
PIN,KICK PEDAL (Ref # 11)	92043-119	1
BOLT-HEX HEAD,10MM (Ref # 12)	92001-085	1
BOLT,HEX HEAD,10X25 (Ref # 12)	113G1025	1
BOSS,KICK PEDAL (Ref # 13)	13061-026	1
WASHER PLAIN 10MM (Ref # 14)	410B1000	1
CIRCLIP,7MM (Ref # 15)	482K7000	1
SPRING KICK PEDAL (Ref # 16)	92081-020	1
BALL STEEL 1/4' (Ref # 17)	600A0800	1
STOPPER,KICKSTARTER (Ref # 18)	13072-014	1
GUIDE,KICKSTARTER (Ref # 19)	13206-1003	1
WASHER,LOCK (Ref # 20)	92031-008	1
BOLT-UPSET,6X16 (Ref # 21)	112G0616	2