


# 1978 SR PARTS DIAGRAM

REAR WHEEL/TIRE/HUB/CHAIN



# 1978 SR PARTS LIST

## REAR WHEEL/TIRE/HUB/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
PIN-COTTER,4.0X35 (Ref # 1)	550D4035	1
NUT CASTLE,16MM (Ref # 2)	92015-055	1
COLLAR,REAR AXLE,22MM (Ref # 3)	92027-1023	1
SPROCKET-HUB,40T,BLAC (Ref # 4)	42041-1100	1
REAR SPROCKET,4/T (Ref # 4)	42041-1024	1
CHAIN-EX50MV-0X102L (Ref # 5)	92057-1232	1
COUPLING ASSY,R.HUB (Ref # 6)	42033-1004	1
NUT 10MM (Ref # 7)	42045-005	6
PLUG (Ref # 8)	92068-007	3
OIL SEAL (Ref # 9)	92050-027	1
CIRCLIP,62M/M (Ref # 10)	92033-1044	1
BALL BEARING,#6206 (Ref # 11)	601B6206	1
SLEEVE,REAR HUB (Ref # 12)	42036-1013	1
BOLT-REAR SPROCKET (Ref # 13)	92003-087	6
COLLAR,FRONT AXLE (Ref # 14)	41069-032	1
AXLE,RR (Ref # 15)	41068-1086	1
SOLID WHEEL ASSY,REAR (Ref # 16)	41073-1011	1
BRG,BALL,#6303ZZC3 (Ref # 17)	601B6303ZZ	2
"0" RING,65MM (Ref # 18)	671B2565	1
SHOCK DAMPER,REAR HUB (Ref # 19)	42014-033	1
COLLAR,REAR HUB BRG. (Ref # 20)	92027-1047	1
CIRCLIP,47M/M (Ref # 21)	92033-1042	1
SEAL-OIL,FORK OUTER (Ref # 22)	92049-1319	1
WASHER,LOCK (Ref # 23)	92088-023	2
BOLT (Ref # 24)	92001-160	4
BALANCER-WHEEL,10G (Ref # 25)	41075-1011	AR
BALANCER-WHEEL,20G (Ref # 26)	41075-1012	AR
BALANCER-WHEEL,30G (Ref # 27)	41075-1013	AR
TUBE 510-16 (Ref # 28)	41022-1003	1

# 1978 SR PARTS LIST

## REAR WHEEL/TIRE/HUB/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
TIRE 510-16 K87 R (Ref # 29)	41002-1020	1