


1970 Bushwhacker PARTS DIAGRAM

FOOTRESTS/STANDS/BRAKE PEDAL



1970 Bushwhacker PARTS LIST

FOOTRESTS/STANDS/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
BAR FOOTREST L.H (Ref # 1)	34003-003	
BAR FOOTREST L.H (Ref # 1)	34003-012	
BAR FOOTREST R.H (Ref # 2)	34003-004	
BAR FOOTREST R.H (Ref # 2)	34003-014	
STAND-SIDE (Ref # 3)	34024-017	
RUBBER FOOTREST (Ref # 4)	92076-010	
RUBBER FOOTREST (Ref # 4)	92076-006	
SPRING FOOTREST PEG (Ref # 5)	34006-002	
WASHER FOLDING PEG (Ref # 6)	92022-049	
WASHER BRAKE PEDAL (Ref # 7)	92022-085	
SPRING,SIDE STAND (Ref # 8)	34025-001	
SPRING BRAKE PEDAL (Ref # 9)	43005-005	
CIRCLIP 16MM (Ref # 10)	480J1600	
BOLT HEX HEAD 12X40 (Ref # 11)	113G1240	
BOLT HEX HEAD 12X40 (Ref # 11)	113G1240	
BOLT HEX HEAD 12X63 (Ref # 11)	113G1263	
BOLT HEX HEAD 12X63 (Ref # 11)	113G1263A	
WASHER SPRING 12MM (Ref # 12)	461F1200	
PIN COTTER 3.0X30 (Ref # 13)	550D3030	
BOLT-UPSET,10X30 (Ref # 14)	112G1030	
NUT 10MM (Ref # 15)	315B1000	
PEDAL BRAKE (Ref # 16)	43001-022	
SHAFT BRAKE PEDAL (Ref # 17)	43004-008	
NUT,12MM (Ref # 18)	314G1200A	
NUT-HEX-FINE (Ref # 18)	314B1200	
STAND-MAIN (Ref # 19)	34011-025	
STAND-MAIN (Ref # 19)	34011-025	
SHAFT MAIN STAND (Ref # 20)	34019-008	
SPRING MAIN STAND (Ref # 21)	34023-005	

1970 Bushwhacker PARTS LIST

FOOTRESTS/STANDS/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
SPRING MAIN STAND (Ref # 21)	34023-005	
BRAKE ROD ASSY (Ref # 22)	43010-5003	
ROD ASSY BRAKE (Ref # 22)	43010-008	
SPRING RR BRKE TORQUE (Ref # 23)	43008-001	
PIN BRAKE (Ref # 24)	92043-039	
NUT-BRAKE ROD ADJUST (Ref # 25)	92015-042	
WASHER PLAIN 5MM (Ref # 26)	410B0500	
PIN COTTER 2.0X15 (Ref # 27)	550D2015	