


# 1969 Bushwhacker PARTS DIAGRAM

## FUEL TANK



# 1969 Bushwhacker PARTS LIST

## FUEL TANK

ITEM NAME	PART NUMBER	QUANTITY
CAP,FUEL TANK LOCKING (Ref # 1)	51048-006	
UNAVAILABLE IN PRICE BOOK (Ref # 2)	51049-003	
DAMPER RUBB TANK FRNT (Ref # 3)	92075-019	
WASHER,8X26X2.3 (Ref # 4)	92022-1564	
UNAVAILABLE IN PRICE BOOK (Ref # 5)	116B08110	
WASHER SPRING 8MM (Ref # 6)	461F0800	
DAMPER RUBB TANK REAR (Ref # 7)	92075-030	
SPACER FUEL TANK REAR (Ref # 8)	92027-034	
BOLT HEX HEAD 8X35 (Ref # 9)	116B0835	
COCK ASSY,FUEL (Ref # 10)	51023-044	
CUP FUEL COCK (Ref # 11)	51036-003	
GASKET FUEL COCK CUP (Ref # 12)	51037-007	
GASKET FUEL COCK JONT (Ref # 13)	51032-001	
GASKET FUEL COCK LEV (Ref # 14)	92065-019	
PIPE-FUEL (Ref # 15)	51044-031	
PIPE-FUEL (Ref # 15)	51044-031	
.GROMMET PIPE (Ref # 16)	92071-038	
PIPE-FUEL (Ref # 17)	51044-031	
.CLAMP FUEL PIPE (Ref # 18)	92037-010	
TANK FUEL SILVER (Ref # 19)	51001-019-14	
UNAVAILABLE IN PRICE BOOK (Ref # 19-1)	51001-046-14	
TANK-FUEL,SILVER (Ref # 19-2)	51001-046-49	
NUT FUEL TANK FRONT (Ref # 20)	92020-007	
NUT,8MM (Ref # 21)	311B0800	
REFLECTOR REFLEX (Ref # 22)	28001-004	
SPACER FUEL TANK MONT (Ref # 23)	51065-001	
GRIP KNEE L.H (Ref # 24)	51061-005	
GRIP KNEE R.H (Ref # 25)	51062-004	
EMBLEM FUEL TANK L.H (Ref # 26)	56013-006	

# 1969 Bushwhacker PARTS LIST

## FUEL TANK

ITEM NAME	PART NUMBER	QUANTITY
EMBLEM FUEL TANK R.H (Ref # 27)	56014-007	
SPACER FL TANK EMBLEM (Ref # 28)	56025-002	
SCREW PAN HEAD 4X8 (Ref # 29)	220E0408	