


1982 CSR Belt PARTS DIAGRAM

REAR HUB/BRAKE/BELT

F2240-0053



1982 CSR Belt PARTS LIST

REAR HUB/BRAKE/BELT

ITEM NAME	PART NUMBER	QUANTITY
SPROCKET,REAR 58T (Ref # 21053)	21053-1011	1
DRUM ASSY,REAR (Ref # 41034)	42005-057	1
RR BRAKE PANEL ASSY (Ref # 41035)	41035-1090	1
SHOE,BRAKE (Ref # 41048)	42019-010	2
CAM SHAFT,REAR BRAKE (Ref # 41050)	42026-026	1
LEVER,FRONT BRAKE CAM (Ref # 41053)	41053-002	1
AXLE,REAR (Ref # 41068)	41068-1061	1
INDICATOR,FR BK SHOE (Ref # 41085)	41085-013	1
COUPLING-ASSY,REAR HU (Ref # 42033)	42033-1043	1
SLEEVE,REAR HUB (Ref # 42036)	42036-030	1
BELT,DRIVE,125T (Ref # 59011)	59011-1011	1
BOLT,8X41 (Ref # 92001)	92001-1478	6
NUT,6MM (Ref # 92015)	41072-007	1
NUT,14MM (Ref # 92015A)	42045-020	1
WASHER,SPROCKET LOCK (Ref # 92022)	92088-019	3
SPACER,REAR HUB BEARG (Ref # 92027)	42010-037	1
COLLAR,REAR AXLE (Ref # 92027A)	42032-076	1
COLLAR-REAR HUB,15X26 (Ref # 92027B)	92027-1349	1
OIL SEAL,RR HUB BRNG (Ref # 92049)	92050-060	1
"0" RING,11MM (Ref # 92055)	92055-004	1
SHOCK DAMPER,REAR HUB (Ref # 92075)	42014-030	1
SPRING,BRAKE SHOE (Ref # 92081)	92081-1766	1
SPRING,BRAKE SHOE (Ref # 92081A)	92081-1550	1
BOLT-UPSET (Ref # 110)	112G0630	1
NUT,8M/M (Ref # 317)	317B0800	6
PIN COTTER 3.0X25 (Ref # 550)	550D3025	1
BEARING BALL #6004 (Ref # 601)	601B6004	1
BEARING BALL #6202 (Ref # 601A)	601B6202	1
BEARING BALL #6302Z (Ref # 601B)	601B6302Z	1