


1982 CSR Belt PARTS DIAGRAM

IGNITION

E1830-0032



1982 CSR Belt PARTS LIST

IGNITION

ITEM NAME	PART NUMBER	QUANTITY
BREAKER,CONTACT (Ref # 21008)	21008-1005	1
BREAKER,CONTACT,LH (Ref # 21008A)	21008-1009	1
BREAKER,CONTACT,RH (Ref # 21008B)	21008-1010	1
CONDENSER (Ref # 21013)	21013-1003	1
FELT OIL (Ref # 21039)	21019-005	1
COIL,IGNITION (Ref # 21121)	21121-093	1
COIL-IGNITION (Ref # 21121A)	21121-1009	1
CAP,SPARK PLUG"LD05F" (Ref # 21130)	21130-1003	2
GOVERNOR-BREAKER (Ref # 21148)	21148-1023	1
HARNESS,BREAKER (Ref # 26001)	26001-1085	1
BOLT,6X14 (Ref # 92001)	92003-221	1
NUT (Ref # 92015)	92019-008	4
WASHER,PLAIN (Ref # 92022)	92022-323	1
UNAVAILABLE IN PRICE BOOK (Ref # 92070)	92070-1034	2
GROMMET,SPARK PLG CAP (Ref # 92071)	21132-005	2
GROMMET,SPARK PLUG (Ref # 92071A)	92071-1015	2
SCREW PAN HEAD 4X6 (Ref # 220)	220B0406	4
SCREW PAN HEAD 5X12 (Ref # 220A)	220B0512	2
SCREW PAN HEAD 6X10 (Ref # 220B)	220B0610	2
WASHER PLAIN 4MM (Ref # 410)	410B0400	4
WASHER PLAIN 6MM (Ref # 411)	411B0600	2
WASHER SPRING 4MM (Ref # 461)	461F0400	4
WASHER SPRING 5MM (Ref # 461A)	461F0500	2
PIN DOWEL 3X8 (Ref # 551)	551A0308	1