


1982 GPz PARTS DIAGRAM

AIR CLEANER

E1130-0074



1982 GPz PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-1122	1
FILTER-ASSY-AIR (Canada) (Ref # 11010A)	11010-1123	1
CASE-AIR FILTER (Ref # 11011)	11011-1104	1
CASE-AIR FILTER (Ref # 11011A)	11011-1105	1
ELEMENT,AIR CLNR (Ref # 11013)	11013-1058	1
ELEMENT,AIR CLNR (Ref # 11013A)	11013-1059	1
COVER,AIR FILTER,LH (Ref # 14025)	14025-1405	1
COVER,AIR FILTER,RH (Ref # 14025A)	14025-1406	1
DUCT,AIR FILTER (Ref # 14073)	14073-1073	4
DUCT,AIR FILTER (Ref # 14073A)	14073-1075	1
VALVE ASSY,AIR SWITCH (Ref # 16126)	16126-1017	1
FITTING,TUBE (Ref # 92005)	92005-1017	1
SCREW,TAPPING,5X12,BL (Ref # 92009)	92009-1138	6
NUT 6MM (Ref # 92015)	92016-062	1
WASHER 6.5X20X1.6T (Ref # 92022)	92022-125	1
CLAMP-PIPE (Ref # 92037)	92037-072	6
CLAMP (Ref # 92037A)	92037-1076	1
CLAMP,BREATHER TUBE (Ref # 92037B)	92037-213	4
TUBE,VACUUM,LONG (Ref # 92059)	92059-1162	2
TUBE,19X21X340L (Ref # 92059A)	92059-1039	1
TUBE,4X9X220L (Ref # 92059B)	92059-1040	1
TUBE,BREATHER,10X63L (Ref # 92059C)	92059-1200	1
TUBE,AIR (Ref # 92059D)	92059-1208	2
GROMMET,AIR CLEANER (Ref # 92071)	92071-1013	1
SPRING,AIR FILTER DUC (Ref # 92081)	92144-1771	4
SCREW PAN HEAD 6X14 (Ref # 220)	220B0614	1
SCREW PAN HEAD 6X16 (Ref # 220A)	220B0616	5
WASHER PLAIN 6MM (Ref # 410)	410B0600	6
WASHER SPRING 6MM (Ref # 461)	461F0600	1

1982 GPz PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
TUBE-RUBBER,4X70 (Ref # 702)	702A0470	1