


1988 Mojave 110E PARTS DIAGRAM

Air Cleaner

E1130-0226



1988 Mojave 110E PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
CASE-AIR FILTER (Ref # 11011)	11011-1235	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1109	1
HOLDER,ELEMENT (Ref # 13091)	13091-1121	1
HOLDER,AIR FILTER (Ref # 13091A)	13091-1441	1
COVER,AIR FILTER (Ref # 14024)	14024-1311	1
DUCT,AIR FILTER (Ref # 14073)	14073-1270	1
DUCT,AIR FILTER (Ref # 14073A)	14073-1290	1
DUCT,AIR FILTER (Ref # 14073B)	14073-1291	1
BOOT (Ref # 49006)	49006-1199	1
ARRESTER-FLAME (Ref # 59006)	59006-1051	1
COLLAR,L=4.6 (Ref # 92027)	92027-1168	2
COLLAR,L=7.4 (Ref # 92027A)	92027-1848	3
CLAMP,39MM (Ref # 92037)	92037-1407	1
CLAMP (Ref # 92037A)	92037-1460	1
CLAMP (Ref # 92037B)	92037-1554	2
CLAMP (Ref # 92037C)	92037-177	1
CLAMP,AIR FILTER (Ref # 92037D)	92037-1783	4
SEAL,AIR FILTER COVER (Ref # 92093)	92093-1221	1
SCREW-PAN-CROS,6X16 (Ref # 220)	220B0616	5