


# 1988 Mojave 110E PARTS DIAGRAM

Engine Cover(s)

E1431-0205



# 1988 Mojave 110E PARTS LIST

## Engine Cover(s)

ITEM NAME	PART NUMBER	QUANTITY
GASKET,14.3X20X1 (Ref # 11009)	11009-1238	1
GASKET,GENERATOR COVER (Ref # 11009A)	11009-1311	1
GASKET,CLUTCH COVER (Ref # 11009B)	11009-1346	1
GASKET,COVER,LH (Ref # 11009C)	11009-1597	1
COVER,LH (Ref # 14024)	14024-1312	1
COVER (Ref # 14024A)	14024-1609	1
COVER-GENERATOR (Ref # 14031)	14031-1198	1
COVER-CLUTCH (Ref # 14032)	14032-1114	1
CAP-OIL FILLER (Ref # 16115)	16115-1009	1
GAUGE,OIL LEVEL (Ref # 52005)	52005-1055	1
SCREW,SOCKET,8X8 (Ref # 92009)	92009-1439	1
BUSHING (Ref # 92028)	92028-1189	2
PIN,6.2X8X14 (Ref # 92043)	92043-1263	4
SEAL-OIL (Ref # 92049)	92049-1163	1
SEAL-OIL,AE2057A0 (Ref # 92049A)	92049-1265	1
RING-O,31.5X2.6 (Ref # 92055)	92055-049	1
PLUG,14X8 (Ref # 92066)	92066-1273	1
SCREW-PAN-CROS (Ref # 220)	220X0630	9
SCREW-PAN-CROS (Ref # 220A)	220X0635	10
SCREW-PAN-CROS (Ref # 220B)	220X0640	1
SCREW-CSK-RD-CROS (Ref # 222)	222C0514	2