


1988 Mojave 110E PARTS DIAGRAM

Front Fender(s)

F2171-0005



1988 Mojave 110E PARTS LIST

Front Fender(s)

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,FLAP (Ref # 11045)	11045-1178	2
COVER,FRONT FENDER,P.WHITE (Ref # 14024)	14024-1307-6F	1
COVER,FRONT FENDER,F.RED (Ref # 14024A)	14024-1307-6L	1
BRACKET-FENDER,FR,LH (Ref # 32065)	32065-1220	1
BRACKET-FENDER,FR,RH (Ref # 32065A)	32065-1221	1
FENDER-FRONT,P.WHITE (Ref # 35004)	35004-1195-6F	1
FENDER-FRONT,F.RED (Ref # 35004A)	35004-1195-6L	1
STAY,FRONT FENDER (Ref # 35011A)	35011-1396	1
FLAP,LH (Ref # 35019)	35019-1181	1
FLAP,RH (Ref # 35019A)	35019-1182	1
BOLT,6X16 (Ref # 92002)	92002-1136	2
SCREW,6X18,BLACK (Ref # 92009)	92009-1181	8
SCREW,6X14 (Ref # 92009A)	92009-1288	2
NUT,CLAMP,6MM (Ref # 92015)	92015-1678	2
WASHER,6.5X20X1.6 (Ref # 92022)	92022-125	2
COLLAR,L=4.6 (Ref # 92027)	92027-1168	2
COLLAR (Ref # 92027A)	92027-1757	2
DAMPER (Ref # 92075)	92075-281	2
BOLT-FLANGED,6X14 (Ref # 130)	130D0614	4
BOLT-FLANGED (Ref # 130A)	130D0640	1
NUT-HEX (Ref # 311)	311H0600	2