


1988 Mojave 110E PARTS DIAGRAM

Rear Hub

F2240-0201



1988 Mojave 110E PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
GASKET (Ref # 11009)	11009-1596	1
CAP,WHEEL (Ref # 11012)	11012-1519	2
ADJUSTER-CHAIN (Ref # 33040)	33040-4006	1
DRUM,REAR BRAKE (Ref # 41038)	41038-1174	1
HOUSING-BEARING (Ref # 41046)	41046-1078	1
SHOE-BRAKE,RR (Ref # 41048)	41048-1025	2
CAM-BRAKE (Ref # 41050)	42026-026	1
LEVER-BRAKE CAM (Ref # 41053)	41053-4004	1
AXLE-ASSY,RR (Ref # 41067)	41067-1297	1
INDICATOR (Ref # 41085)	41085-1058	1
SPROCKET-HUB,50T (Ref # 42041)	42041-1261	1
HUB,RR (Ref # 49030)	49030-1081	2
GUARD,REAR BRAKE DRUM (Ref # 55020)	55020-1233	1
BOLT,10MM (Ref # 92002)	92002-1459	8
NUT,FLANGED,6MM (Ref # 92015)	92015-1193	1
NUT,FLANGED,10MM (Ref # 92015A)	92015-1335	4
NUT,CASTLE,18MM (Ref # 92015B)	92015-1441	2
NUT,LOCK,32MM (Ref # 92015C)	92015-1493	2
WASHER,12.4X28X4.5 (Ref # 92022)	92022-1196	3
WASHER,32.5X43X2.3 (Ref # 92022A)	92022-1225	1
WASHER,T=4.5 (Ref # 92022B)	92022-1794	2
COTTER,4.0X35 (Ref # 92041)	92041-1053	2
RING-O,BRAKE CAM (Ref # 92055)	92055-004	1
CHAIN,DRIVE,DID428VX100L (Ref # 92057)	92057-1218	1
SPRING,BRAKE SHOE (Ref # 92081)	92081-1550	1
SPRING,BRAKE SHOE (Ref # 92081A)	92081-1766	1
SEAL (Ref # 92093)	92093-1229	1
COLLAR,35.7X41.3X125 (Ref # 92143)	92143-1024	1
BOLT-UPSET (Ref # 112)	112H0640	1

1988 Mojave 110E PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FINE-WS (Ref # 160)	160H1225	4
BOLT-UPSET-WS (Ref # 180)	180D0612	4
NUT-HEX-SMALL,8MM (Ref # 318)	318G0800	2
WASHER-PLAIN,8MM (Ref # 411)	411B0800	1
BEARING-BALL,#6007UU (Ref # 601)	601A6007UU	2