


2008 Ninja® 500R PARTS DIAGRAM

Water Pump



2008 Ninja® 500R PARTS LIST

Water Pump

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL,6X12 (Ref # 132)	132BB0612	1
BOLT-FLANGED-SMALL,6X30 (Ref # 132A)	132BB0630	1
BOLT-FLANGED-SMALL,6X35 (Ref # 132B)	132BB0635	3
WASHER-PLAIN,6.5X13X1 (Ref # 411)	411AB0600	1
GASKET (Ref # 11061)	11061-0107	1
GASKET,PUMP HOUSING (Ref # 11061A)	11061-0276	1
GASKET,PUMP COVER (Ref # 11061B)	11061-0277	1
SHAFT,IMPELLER (Ref # 13107)	13107-1203	1
HOUSING,WATER PUMP (Ref # 13227)	13227-1064	1
COVER-PUMP (Ref # 16142)	16142-1073	1
SEAL-MECHANICAL (Ref # 49063)	49063-1056	1
IMPELLER (Ref # 59256)	59256-1060	1
PIN,6.2X8X14 (Ref # 92043)	92043-1263	2
SEAL-OIL,SC12365 (Ref # 92049)	92049-1215	1