


2008 Ninja® ZX™-6R PARTS DIAGRAM

Throttle

E1510



2008 Ninja® ZX™-6R PARTS LIST

Throttle

ITEM NAME	PART NUMBER	QUANTITY
CAP (Ref # 11065)	11065-0018	4
PLATE (Ref # 13271)	13271-0559	1
SCREW-PILOT AIR (Ref # 16014)	16014-0002	4
SCREW-THROTTLE STOP (Ref # 16021)	16021-0014	1
INSULATOR (Ref # 16073)	16073-3707	4
THROTTLE-ASSY,TTK38 (Ref # 16163)	16163-0085	1
PIPE-COMP,FUEL (Ref # 31064)	31064-0023	1
NOZZLE-INJECTION (Ref # 49033)	49033-0013	4
PIPE-INJECTION (Ref # 49056)	49056-0014	2
JOINT,3WAY,T (Ref # 59071)	59071-3752	3
RING-O,INJECTION NOZZLE (Ref # 92055)	92055-1622	4
SPRING (Ref # 92144)	92144-1451	1
SPRING (Ref # 92145)	92145-0294	1
SPRING,THROTTLE SYNCRO (Ref # 92145A)	92145-0510	1
BOLT,5X8 (Ref # 92150)	92150-1406	1
CLAMP (Ref # 92171)	92171-0359	1
SCREW,PIPE INJECTION (Ref # 92172)	92172-0064	4
SCREW (Ref # 92172A)	92172-0129	1
SCREW,THROTTLE SYNCRO (Ref # 92172B)	92172-0309	1
TUBE,3X7X40 (Ref # 92191)	92191-0022	2
TUBE,3X7X100 (Ref # 92191A)	92191-0023	2
TUBE,3X7X30 (Ref # 92191B)	92191-0025	2