


# 2008 Ninja® ZX™-6R PARTS DIAGRAM

## Fuel Injection

E1530



## 2008 Ninja® ZX™ -6R PARTS LIST

### Fuel Injection

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,5X22 (Ref # 120)	120CB0522	2
CONTROL UNIT-ELECTRONIC (Ref # 21175)	21175-0111	1
SENSOR,VEHICLE-DOWN (Ref # 21176)	21176-0026	1
SENSOR,CAM (Ref # 21176A)	21176-0034	1
SENSOR,PRESSURE (Ref # 21176B)	21176-0058	2
SENSOR,WATER TEMP (Ref # 21176C)	21176-1120	1
SENSOR,AIR TEMP (Ref # 21176D)	21176-2106	1
RING-O (Ref # 92055)	92055-1639	1
GASKET,12X22X2 (Ref # 92065)	92065-097	1
GROMMET,10.9X25X11.6 (Ref # 92071)	92071-0033	1
DAMPER (Ref # 92075)	92075-1912	2
BOLT,FLANGED,6X16 (Ref # 92151)	92151-1774	1
COLLAR (Ref # 92152)	92152-0134	2
DAMPER (Ref # 92161)	92161-0041	2
DAMPER,ECU (Ref # 92161A)	92161-0381	1
CLAMP,HOSE (Ref # 92170)	92170-1128	1
TUBE,L=300MM (Ref # 92192)	92192-0352	1
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	2