


1998 Bayou 400 4X4 PARTS DIAGRAM

Crankcase



1998 Bayou 400 4X4 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,6X16 (Ref # 120)	120P0616	4
BOLT-FLANGED-SMALL (Ref # 132)	132Y0635	9
BOLT-FLANGED-SMALL (Ref # 132A)	132Y0675	3
BOLT-FLANGED-SMALL (Ref # 132B)	132Y0685	1
BOLT-FLANGED-SMALL (Ref # 132C)	132Y0695	4
SCREW-PAN-CROS,6X14 (Ref # 220)	220B0614	6
BEARING-BALL (Ref # 601)	601A6203Z	2
GASKET,OIL LINE (Ref # 11060)	11060-1710	1
GUIDE (Ref # 13070)	13070-1254	1
GUIDE,CHAIN (Ref # 13070A)	13070-1255	1
PLATE,OIL LINE (Ref # 13183)	13183-1725	1
PLATE-POSITION (Ref # 14014)	14014-1069	1
PLATE-POSITION (Ref # 14014A)	14014-1107	1
PLATE-POSITION (Ref # 14014B)	14014-1108	1
FITTING,BREATHER (Ref # 14067)	14067-006	1
SCREW,6X14 (Ref # 92009)	92009-1349	3
BUSHING,26X35X14 (Ref # 92028)	92028-131	1
BUSHING,23X30X13 (Ref # 92028A)	92028-132	1
BUSHING (Ref # 92028B)	92028-1386	1
BUSHING,14X16X15 (Ref # 92028C)	92028-1505	1
CLAMP (Ref # 92037)	92037-1860	1
PIN,11.5X14X14 (Ref # 92043)	92043-1279	2
BEARING-BALL,TMB304CCM (Ref # 92045)	92045-1142	2
BEARING-BALL,6305RHR4SH2 (Ref # 92045A)	92045-1254	1
BEARING-BALL,63/22 (Ref # 92045B)	92045-1255	1
BEARING-BALL,6307SH2-9C4 (Ref # 92045C)	92045-1257	1
BEARING-BALL,6208RSH2-9C3 (Ref # 92045D)	92045-1258	1
SEAL-OIL,AC1013A1 (Ref # 92049)	92049-1393	1
GASKET,12X22X2,DRAIN PLUG (Ref # 92065)	92065-097	1

1998 Bayou 400 4X4 PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
PLUG,OIL DRAIN,12X15 (Ref # 92066)	92066-1174	1
BOLT,RETURN SPRING (Ref # 92150)	92150-1467	1
WASHER,50X60.5X0.5 (Ref # 92200)	92200-1106	1
SET-CRANKCASE (Ref # 14001)	14001-5344	1
BOOT (Ref # 49006)	49006-1199	1
TUBE-ASSY (Ref # 51044)	51044-1118	1
TUBE,BREATHER (Ref # 92191)	92191-1176	1