

2007 Ninja® ZX™-6R PARTS LIST

Chassis Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X10 (Ref # 130)	130BA0610	1
BOLT-FLANGED,6X12 (Ref # 130A)	130BA0612	1
BRACKET,RELAY BOX (Ref # 11054)	11054-0865	1
FUSE,15A (Ref # 26006)	26006-0001	2
FUSE,10A (Ref # 26006A)	26006-1078	7
WIRE-LEAD (Ref # 26011)	26011-0037	1
WIRE-LEAD,BATTERY(-) (Ref # 26011A)	26011-0128	1
WIRE-LEAD,BATTERY(+) (Ref # 26011B)	26011-1764	1
BATTERY,YTX9-BS,12V 8AH (Ref # 26012)	26012-0088	1
HARNESS,MAIN (Ref # 26031)	26031-0561	1
RELAY-ASSY (Ref # 27002)	27002-0007	1
RELAY-ASSY,TURN SIGNAL (Ref # 27002A)	27002-1101	1
HORN (Ref # 27003)	27003-0030	1
LABEL,FUSE BOX (Ref # 56030)	56030-0091	1
LABEL,FUSE BOX (Ref # 56030A)	56030-0139	1
CLAMP,HOSE (Ref # 92037)	92037-1827	3
BAND,L=140 (Ref # 92072)	92072-1293	2
BOLT,SOCKET,6X10 (Ref # 92153)	92153-0410	1
DAMPER,RELAY BOX (Ref # 92161)	92161-0203	1
CLAMP (Ref # 92170)	92170-1577	1
CLAMP (Ref # 92171)	92171-0011	1
CLAMP,BRAKE HOSE (Ref # 92171A)	92171-0316	4
CLAMP (Ref # 92171B)	92171-0462	1
CLAMP (Ref # 92171C)	92171-0652	1
CLAMP (Ref # 92171D)	92171-0974	2
SCREW,TAPPING,5X16 (Ref # 92172)	92172-0175	2