


1997 Mojave 250 PARTS DIAGRAM

Valve(s)

E1210



1997 Mojave 250 PARTS LIST

Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
GASKET,14X18X1.5 (Ref # 11009)	11009-1430	1
VALVE-INTAKE (Ref # 12004)	12004-1119	2
VALVE-EXHAUST (Ref # 12005)	12005-1052	2
RETAINER-VALVE SPRING (Ref # 12009)	12009-1054	4
COLLET (Ref # 12011)	12011-1003	8
ARM-ROCKER,INTAKE (Ref # 12016)	12016-1071	1
ARM-ROCKER,EXHAUST (Ref # 12016A)	12016-1083	1
SHAFT-ROCKER,INTAKE (Ref # 12020)	12020-1055	1
SHAFT-ROCKER,EXHAUST (Ref # 12020A)	12020-1056	1
SEAT-SPRING,12.1X16.2X0.5 (Ref # 16007)	16007-1177	4
SEAT-SPRING,17.5X23.8X0.5 (Ref # 16007A)	16007-1178	4
SPRING-ENGINE VALVE,INNER (Ref # 49078)	49078-1051	4
SPRING-ENGINE VALVE,OUTER (Ref # 49078A)	49078-1056	4
SCREW,7MM (Ref # 92009)	92009-1279	4
NUT,7MM (Ref # 92015)	92015-1325	4
SEAL-OIL,RVC2-5.5X8.5X8.3 (Ref # 92049)	92049-1062	4
SPRING,ROCKER ARM (Ref # 92081)	92081-1740	2