


1998 Mojave 250 PARTS DIAGRAM

Front Hub

F2230



1998 Mojave 250 PARTS LIST

Front Hub

ITEM NAME	PART NUMBER	QUANTITY
PIN-COTTER,4.0X30 (Ref # 550)	550D4030	2
CAP,WHEEL (Ref # 11012)	11012-1969	2
HUB,FR (Ref # 49030)	49030-1084	2
BOLT,10X30 (Ref # 92002)	92002-1388	8
NUT,CASTLE,16MM (Ref # 92015)	92015-1947	2
COLLAR,16.0X22X9.5 (Ref # 92027)	92027-1815	2
BEARING-BALL,60/222RS (Ref # 92045)	92045-1170	2
BEARING-BALL,6203DDU2 AV2S (Ref # 92045A)	92045-1228	2
SEAL-OIL,SDD4 28 44 8 (Ref # 92049)	92049-1260	2
SEAL-OIL (Ref # 92049A)	92049-1318	2
RING-O,21.5MM (Ref # 92055)	92055-1293	2
COLLAR,L=25 (Ref # 92143)	92143-1007	2
COLLAR,L=14.1 (Ref # 92143A)	92143-1008	2