

1998 Mojave 250 PARTS LIST

Front Hub

| ITEM NAME | PART NUMBER | QUANTITY |
|---|-------------|----------|
| PIN-COTTER,4.0X30 (Ref # 550) | 550D4030 | 2 |
| CAP,WHEEL (Ref # 11012) | 11012-1969 | 2 |
| HUB,FR (Ref # 49030) | 49030-1084 | 2 |
| BOLT,10X30 (Ref # 92002) | 92002-1388 | 8 |
| NUT,CASTLE,16MM (Ref # 92015) | 92015-1947 | 2 |
| COLLAR,16.0X22X9.5 (Ref # 92027) | 92027-1815 | 2 |
| BEARING-BALL,60/222RS (Ref # 92045) | 92045-1170 | 2 |
| BEARING-BALL,6203DDU2 AV2S (Ref # 92045A) | 92045-1228 | 2 |
| SEAL-OIL,SDD4 28 44 8 (Ref # 92049) | 92049-1260 | 2 |
| SEAL-OIL (Ref # 92049A) | 92049-1318 | 2 |
| RING-O,21.5MM (Ref # 92055) | 92055-1293 | 2 |
| COLLAR,L=25 (Ref # 92143) | 92143-1007 | 2 |
| COLLAR,L=14.1 (Ref # 92143A) | 92143-1008 | 2 |