


1998 Mojave 250 PARTS DIAGRAM

Guard(s)



1998 Mojave 250 PARTS LIST

Guard(s)

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X10 (Ref # 130)	130B0610	2
BOLT-FLANGED,8X25 (Ref # 130A)	130G0825	1
BOLT-FLANGED,8X30 (Ref # 130B)	130J0830	1
BOLT-FLANGED (Ref # 130C)	130Z0865	2
BOLT-UPSET-WS,6X16 (Ref # 180)	180G0616	5
SCREW-PAN-CROS,6X30,BLACK (Ref # 220)	220C0630	2
BUMPER-FRONT (Ref # 39027)	39027-1051	2
GUARD,FRONT HUB,INNER,LH (Ref # 55020)	55020-1223	1
GUARD,FRONT HUB,INNER,RH (Ref # 55020A)	55020-1224	1
GUARD,FRONT HUB,OUTER (Ref # 55020B)	55020-1263	2
GUARD,ENGINE,F.RED (Ref # 55020D)	55020-1458-CD	1
GUARD,RR (Ref # 55020E)	55020-1525	1
NUT,FLANGED,6MM,BLACK (Ref # 92015)	92015-1233	2
NUT,8MM (Ref # 92015A)	92015-1432	2
WASHER,6.5X20X1.6 (Ref # 92022)	92022-125	5
WASHER,7X16X1.2 (Ref # 92022A)	92022-1344	4
COLLAR,10X21.3X7 (Ref # 92027)	92027-1817	4
COLLAR,6.8X10X20 (Ref # 92027A)	92027-1856	2
DAMPER,INNER (Ref # 92075)	92075-1822	6
DAMPER (Ref # 92075A)	92075-1828	2
DAMPER (Ref # 92075B)	92075-1829	2
DAMPER (Ref # 92075C)	92075-1872	1
DAMPER (Ref # 92160)	92160-1102	1