


# 2004 KFX400 PARTS DIAGRAM

Rear Hub(A2)

F2240A



## 2004 KFX400 PARTS LIST

### Rear Hub(A2)

ITEM NAME	PART NUMBER	QUANTITY
VALVE,WHEEL RIM,TR412 (Ref # 16126)	16126-S002	2
PIN-HAIR,REAR HUB (Ref # 39092)	39092-S010	2
TIRE,RR (Ref # 41009)	41009-S013	2
RIM,REAR WHEEL,9X8.0AT (Ref # 41025)	41025-S009	2
HOUSING-BEARING (Ref # 41046)	41046-S004	1
HOUSING-BEARING (Ref # 41046A)	41046-S006	1
AXLE,RR (Ref # 41068)	41068-S015	1
DISC,REAR BRAKE (Ref # 41080)	41080-S006	1
SPROCKET-HUB (Ref # 42041)	42041-S006	1
HUB,RR,F.GRAY (Ref # 49030)	49030-S004-563	2
SPACER,REAR AXLE (Ref # 92026)	92026-S106	1
BEARING-BALL,REAR AXLE (Ref # 92045)	92045-S049	2
SEAL-OIL,AXLE (Ref # 92049)	92049-S052	2
BOLT,REAR SPROCKET (Ref # 92153)	92153-S277	4
BOLT (Ref # 92153A)	92153-S283	4
WASHER,REAR SPROCKET (Ref # 92200)	92200-S139	4
WASHER,REAR HUB (Ref # 92200A)	92200-S141	2
WASHER,REAR AXLE (Ref # 92200B)	92200-S143	2
NUT,WHEEL (Ref # 92210)	92210-S100	8
NUT,REAR AXLE (Ref # 92210A)	92210-S109	1
NUT,REAR AXLE (Ref # 92210B)	92210-S110	1
NUT,REAR HUB (Ref # 92210C)	92210-S113	2