


# 2005 KFX50 PARTS DIAGRAM

## Knuckle Arm

F2145



## 2005 KFX50 PARTS LIST

### Knuckle Arm

ITEM NAME	PART NUMBER	QUANTITY
PIN-HAIR,COTTER (Ref # 39092)	39092-S005	6
ROD-TIE,STEERING (Ref # 39111)	39111-S002	2
RODEND-TIE,RH (Ref # 39112)	39112-S001	2
RODEND-TIE,LH (Ref # 39112A)	39112-S002	2
KNUCKLE,RH (Ref # 39186)	39186-S001	1
KNUCKLE,LH (Ref # 39186A)	39186-S002	1
SPACER (Ref # 92026)	92026-S060	2
SEAL,KNUCKLE ARM DUST (Ref # 92093)	92093-S017	4
BUSHING (Ref # 92139)	92139-S013	4
BOLT,KNUCKLE ARM (Ref # 92153)	92153-S202	2
WASHER,STEERING SHAFT,LWR (Ref # 92200)	92200-S096	6
WASHER,ROD-END (Ref # 92200A)	92200-S097	6
NUT (Ref # 92210)	92210-S036	2
NUT,STEERING SHAFT (Ref # 92210A)	92210-S071	4
NUT,TIE-ROD (Ref # 92210B)	92210-S072	2
NUT,TIE-ROD (Ref # 92210C)	92210-S073	2