



# 2008 ZZR® 600 PARTS DIAGRAM

Fuel Tank



(51083/A~D)  
(51084/A)



WD

('06)	(51084/A)	Silver
('07)	(51083/C)	Ebony
	(51083B/D)	Red
('08)	(51083A)	Blue

## 2008 ZZR® 600 PARTS LIST

### Fuel Tank

ITEM NAME	PART NUMBER	QUANTITY
PAD,FUEL TANK,CNT (Ref # 39156)	39156-1612	1
PAD,FUEL TANK,LH (Ref # 39156A)	39156-1613	1
PAD,FUEL TANK,RH (Ref # 39156B)	39156-1614	1
PACKING,TAP VALVE (Ref # 43049)	43049-1099	1
RING,TAP LEVER (Ref # 43058)	43058-1083	1
TAP-ASSY,FUEL (Ref # 51023)	51023-1318	1
CAP-TANK,FUEL (Ref # 51049)	51049-0021	1
BOLT-SOCKET,5X16 (Ref # 120)	120S0516	3
SCREW-PAN-CROSS,4X16 (Ref # 220)	220F0416	1
TUBE-RUBBER,6X520 (Ref # 702)	702A06520	1
TANK-COMP-FUEL,EBONY (Ref # 51083)	51083-5369-H8	1
TANK-COMP-FUEL,C.P.BLUE (Ref # 51083A)	51083-5369-723	1
TRIM (Ref # 53044)	53044-1296	1
LABEL,FUEL TAP (Ref # 56030)	56030-1195	1
SCREW,3X8 (Ref # 92009)	92009-1386	2
CLAMP,TUBE (Ref # 92037)	92037-010	1
RING-O,FUEL TAP PACKING (Ref # 92055)	92055-1112	1
DAMPER (Ref # 92075)	92075-209	2
KNOB,FUEL TAP (Ref # 92077)	92077-1123	1
COLLAR (Ref # 92143)	92143-1515	2
BOLT,SOCKET,6X35 (Ref # 92151)	92151-1835	4
COLLAR (Ref # 92152)	92152-1266	2
BOLT,FLANGED,6X25 (Ref # 92153)	92153-0514	2
DAMPER (Ref # 92160)	92160-1162	2
WASHER,6.5X11.5X0.8 (Ref # 92200)	92200-0117	2
WASHER,6.5X22X1.6 (Ref # 92200A)	92200-1087	2