


1999 Prairie 300 4X4 PARTS DIAGRAM

Ignition Switch



1999 Prairie 300 4X4 PARTS LIST

Ignition Switch

| ITEM NAME | PART NUMBER | QUANTITY |
|---|-------------|----------|
| SWITCH-COMP,D.C.TERMINAL (Ref # 13151) | 13151-1087 | 1 |
| COVER,KEY (Ref # 14024) | 14024-1551 | 4 |
| LAMP-ASSY,NEUTRAL&REVERSE (Ref # 23016) | 23016-1083 | 1 |
| SWITCH-ASSY-IGNITION (Ref # 27005) | 27005-1201 | 1 |
| KEY-LOCK,BLANK (Ref # 27008) | 27008-1041 | 1 |
| KEY-LOCK,BLANK (Ref # 27008A) | 27008-1042 | 1 |
| KEY-LOCK,BLANK (Ref # 27008B) | 27008-1043 | 1 |
| KEY-LOCK,BLANK (Ref # 27008C) | 27008-1044 | 1 |
| KEY-LOCK,BLANK,W/COVER (Ref # 27008D) | 27008-1132 | 1 |
| KEY-LOCK,BLANK,W/COVER (Ref # 27008E) | 27008-1133 | 1 |
| KEY-LOCK,BLANK,W/COVER (Ref # 27008F) | 27008-1134 | 1 |
| KEY-LOCK,BLANK,W/COVER (Ref # 27008G) | 27008-1135 | 1 |
| BULB,12V 3W,T7 (Ref # 92069) | 92069-1020 | 2 |
| NUT,IGNITION SWITCH (Ref # 92210) | 92210-1109 | 1 |