


2008 Vulcan® 1600 Nomad™ PARTS DIAGRAM

Frame

F2120



2008 Vulcan® 1600 Nomad™ PARTS LIST

Frame

ITEM NAME	PART NUMBER	QUANTITY
PIPE-COMP,BLACK (Ref # 31064)	31064-0042-18R	1
FRAME-COMP (Ref # 32160A)	32160-0267	1
NUT,FLANGED,10MM (Ref # 92015)	92015-1727	2
NUT,POP,6MM,L=16.5 (Ref # 92015A)	92015-1792	2
NUT,STEERING STEM,35MM (Ref # 92015B)	92015-1848	1
SEAL-OIL,XMHE 43 55 4J (Ref # 92049)	92049-1383	1
SEAL-OIL,MX043N2 (Ref # 92049A)	92049-1483	1
RING-O,34.5X2.0 (Ref # 92055)	92055-1452	1
RING-O,ID=24.5 (Ref # 92055A)	92055-1459	1
PLUG (Ref # 92066)	92066-1562	2
BEARING-ROLLER,32907JR-2 (Ref # 92116)	92116-1072	1
BEARING-ROLLER,32907JR-3 (Ref # 92116A)	92116-1074	1
BOLT,SOCKET,10X30 (Ref # 92150)	92150-1690	2
BOLT,SOCKET,10X23 (Ref # 92150A)	92150-1942	2
WASHER,25.5X42X2.3 (Ref # 92200)	92200-0105	1
WASHER,CLAW,25.5X40X2.3 (Ref # 92200A)	92200-1083	1
NUT,CAP,25MM (Ref # 92210)	92210-1166	1